

Stresstech Group Product News

Number XR-1/February 09, 2007

SAFETY ENCLOSURES FOR XSTRESS 3000

Depending on the stress measurement environment, X-ray radiation equipment such as XSTRESS 3000 systems sometimes needs exterior safety measures. XSTRESS 3000 systems can be equipped with different types of safety enclosures to protect users from radiation, and to keep the measurement area clean and undisturbed.

Safety enclosure surrounds either the actual X-ray measurement area, or the whole system can be protected with a fence or safety room. The doors of the enclosure can be equipped with safety door locks, which when opened shut down the X-ray system. Signal light tower telling about the status of the measurement is part of the safety system.



Safety enclosure protecting measurement area on the table for electropolishing.



Safety room.



Examples of various safety enclosures.